

II

1106* ENGLAND - East Coast - Traffic flow direction.

Source: Port of London Authority

Chart 1185 (INT 1572) [*previous update 203/24*] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 266°, centred on:	51° 29'·49N., 0° 48'·89E.
	established direction of traffic flow arrow, direction 282°, centred on:	51° 29'·63N., 0° 44'·88E.
	established direction of traffic flow arrow, direction 272°, centred on:	51° 30'·16N., 0° 39'·51E. 51° 30'·28N., 0° 34'·74E.
	established direction of traffic flow arrow, direction 089°, centred on:	51° 30'·10N., 0° 33'·05E.
	established direction of traffic flow arrow, direction 092°, centred on:	51° 29'·95N., 0° 38'·83E.
	established direction of traffic flow arrow, direction 101°, centred on:	51° 29'·36N., 0° 45'·12E.
	established direction of traffic flow arrow, direction 086°, centred on:	51° 29'·25N., 0° 48'·84E.

Chart 1186 (INT 1426) (Panel A, Canvey Island to Coalhouse Point) [*previous update 646/24*] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 272°, centred on:	51° 30'·249N., 0° 36'·121E. 51° 30'·293N., 0° 34'·396E.
	established direction of traffic flow arrow, direction 267°, centred on:	51° 30'·315N., 0° 32'·755E.
	established direction of traffic flow arrow, direction 260°, centred on:	51° 30'·262N., 0° 31'·404E.
	established direction of traffic flow arrow, direction 080°, centred on:	51° 30'·025N., 0° 31'·585E.
	established direction of traffic flow arrow, direction 090°, centred on:	51° 30'·106N., 0° 32'·870E.
	established direction of traffic flow arrow, direction 094°, centred on:	51° 30'·047N., 0° 34'·337E.
	established direction of traffic flow arrow, direction 093°, centred on:	51° 30'·025N., 0° 36'·083E.

Chart 1606 [*previous update 196/24*] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 054°, centred on:	51° 33'·47N., 1° 10'·06E. 51° 32'·10N., 1° 07'·42E.
	established direction of traffic flow arrow, direction 234°, centred on:	51° 32'·33N., 1° 07'·21E. 51° 33'·27N., 1° 10'·40E.

Chart 1607 (INT 1562) [*previous update 638/24*] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 267°, centred on:	51° 29'·61N., 0° 52'·37E.
	established direction of traffic flow arrow, direction 086°, centred on:	51° 29'·33N., 0° 51'·91E.

II

1106* ENGLAND - East Coast - Traffic flow direction. (continued)

Chart 1609 [previous update 638/24] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 234°, centred on:	51° 33'·47N., 1° 10'·07E. 51° 32'·32N., 1° 07'·21E.
	established direction of traffic flow arrow, direction 266°, centred on:	51° 29'·56N., 0° 51'·42E.
	established direction of traffic flow arrow, direction 088°, centred on:	51° 29'·34N., 0° 51'·18E.
	established direction of traffic flow arrow, direction 055°, centred on:	51° 32'·08N., 1° 07'·42E. 51° 33'·27N., 1° 10'·39E.

Chart 5606_7 [previous update 2202/23] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 266°, centred on:	51° 29'·49N., 0° 48'·89E.
	established direction of traffic flow arrow, direction 282°, centred on:	51° 29'·63N., 0° 44'·88E.
	established direction of traffic flow arrow, direction 102°, centred on:	51° 29'·36N., 0° 45'·12E.
	established direction of traffic flow arrow, direction 086°, centred on:	51° 29'·25N., 0° 48'·84E.

Chart 5606_8 [previous update 203/24] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 272°, centred on:	51° 30'·16N., 0° 39'·51E. 51° 30'·28N., 0° 34'·74E.
	established direction of traffic flow arrow, direction 089°, centred on:	51° 30'·10N., 0° 33'·05E.
	established direction of traffic flow arrow, direction 092°, centred on:	51° 29'·95N., 0° 38'·83E.

Chart 5606_9 [previous update 2202/23] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 266°, centred on:	51° 29'·49N., 0° 48'·90E.
	established direction of traffic flow arrow, direction 282°, centred on:	51° 29'·63N., 0° 44'·88E.
	established direction of traffic flow arrow, direction 102°, centred on:	51° 29'·36N., 0° 45'·12E.
	established direction of traffic flow arrow, direction 086°, centred on:	51° 29'·25N., 0° 48'·84E.

Chart 5606_5 [previous update 447/24] ETRS89 DATUM

Delete	established direction of traffic flow arrow, direction 267°, centred on:	51° 29'·61N., 0° 52'·37E.
	established direction of traffic flow arrow, direction 086°, centred on:	51° 29'·33N., 0° 51'·91E.